

Cat® **TH337**

Telehandler

Specifications

Engine	
Model	
Standard	Cat® C4.4 DITAAC
Optional	Cat® C4.4 DITAAC ACERT®
Gross Power	
Standard	74.5 kW/101 hp
Optional	93.1 kW/126 hp
Maximum Torque	
Standard	410 Nm/1400 rpm
Optional	496 Nm/1400 rpm
Bore	105 mm
Stroke	127 mm
Displacement	4.4 litre

• All engine horsepower (hp) are metric.

Weights

Tyres Standard

Brakes

Service Brakes

Parking Brakes

Operating Weight with Carriage & Forks	
Non-Agriculture	7073 kg
Agriculture	7193 kg
Operating Specifications	
Rated Load Capacity	3300 kg
Maximum Lift Height	7300 mm
Maximum Forward Reach	3763 mm
Top Travel Speed	40 km/h
Load at Max Height	2000 kg
Load at Max Reach	1000 kg
Outside Turning Radius Over Tyres	3750 mm
Outside Turning Radius Over Forks	4740 mm
Service Refill Capacities	
Fuel Tank	150 litre
Hydraulic Tank	90 litre

15.5/80-24 16PR

Servo assisted on front axle

Mechanical on front axle

U	hei	a	ιι
_			

Sound

Operator Sound	78 dB(A)
Exterior Sound	
(74.5 kW Engine)	106 dB (A)
(93.1 kW Engine)	107 dB (A)

Hydraulic System

, ,	
Maximum System Pressure	250 bar
Maximum Pump Flow	113 litre/min
Pump Type	Variable Displacement Load Sensing Axial Piston Pump
Auxiliary Hydraulic Supply	
Intermittent	80 litre/min
Continuous	60 litre/min

Transmission Speeds

Forward	km/h	
1	7	
2	12	
3	21	
4	32	
5 (ACERT engine option only)	40	
Reverse		
1	7	
2	12	
3	21	
Boom Performance		


Boom Up	8.5 Seconds
Boom Down	6.1 Seconds
Tele In	6.0 Seconds
Tele Out	6.0 Seconds
Crowd Forward (dump)	3.0 Seconds
Crowd Backward	3.0 Seconds
Combined	
Up and Out	12.5 Seconds
Down and In	7.6 Seconds
Drawbar Pull 74.5 kW	83,4 kN
Drawbar Pull 93.1 kW	87,3 kN
Bucket Breakout force to ISO 8313	65 kN
Boom Breakout force	42 kN




TH337 Telehandler

Dimensions

All dimensions are approximate.



Load Chart and Dimensions



IMPORTANT

Rated lift capacities shown are with machine equipped with carriage and pallet forks. The machine must be level on a firm surface with undamaged, properly inflated tires. Machine specifications and stability are based on rated lift capacities at specific boom angles and boom lengths. (If specifications are critical, the proposed application should be discussed with your dealer.)

DO NOT exceed rated lift capacity loads, as unstable and dangerous machine conditions will result.

DO NOT tip the machine forward to determine the allowable load.

Due to continuous product improvements, machine specifications and/or equipment changes may be made without prior notification.

www.cat.com

HEHB3868-04 (02-2010)